



NOTES:

1. LOCATE MANHOLE COVER ON DOWNSTREAM SIDE OF MANHOLE. SET MANHOLE FRAME IN GROUT.
2. ALL JOINTS TO BE WATER TIGHT
3. MANHOLE BASE AND 1st SECTION OF MANHOLE TO BE FABRICATED AS AN INTEGRAL UNIT.
4. USE 5' DIAMETER MANHOLE FOR PIPE GREATER THAN 18" DIAMETER PIPE  
USE 4' DIAMETER MANHOLE FOR ALL PIPE UP TO AND INCLUDING 18" DIAMETER PIPE.

## PRECAST CONCRETE SEWER MANHOLE

N.T.S.

06/08

|  |
|--|
| <p>HEBER CITY<br/>STANDARD DRAWING<br/>SEWER-5</p> |
|--|