



- NOTE: 1. RAISE VALVE BOX TO GRADE AFTER PAVING OPERATIONS ARE COMPLETED.  
 2. INSTALL VALVE EXTENSION IF OPERATING NUT IS 2 FEET BELOW THE LID.  
 3. GRIND SMALL SLOT FOR TRACER WIRE TO PASS THROUGH AT FLARE IN VALVE BOX.

NOTE: ALL IRRIGATION BOXES TO BE INSTALLED USING THE ABOVE LID REF#: M-9009

## VALVE BOXES & COLLARS

N.T.S.